Exhibit 6

Eufy - Cameras (See product list at end of chart for models) Infringement of the '242 patent		
Claim 1	Evidence	
1. A method of processing imaging signals, the method	The Eufy Camera performs a method of processing imaging signals.	
comprising:	For example, the Eufy Camera includes an image capturing subsystem, an image processing subsystem, and an interface subsystem connecting them. The image processing subsystem processes imaging signals that are received from the image capturing subsystem via the interface subsystem.	
receiving image data from an imaging array;	The Eufy Camera receives image data from an imaging array.	
	For example, the image capturing subsystem includes a CMOS image sensor that includes an imaging array. The imaging array produces image data when exposed to an image. The interface subsystem of the Eufy Camera receives the image data from the imaging array.	
storing the image data in a FIFO memory;	The Eufy Camera stores the image data in a FIFO memory.	
	For example, the interface subsystem includes a FIFO memory for storing image data. The image data received from the imaging array is stored in the FIFO memory by the interface subsystem.	
updating a FIFO counter to maintain a count of the image data in the FIFO memory in response	The Eufy Camera updates a FIFO counter to maintain a count of the image data in the FIFO memory in response to memory reads and writes;	
to memory reads and writes;	For example, the interface subsystem includes a FIFO counter to maintain a count of the image data, or "fill level", that is stored in the FIFO memory. When a unit of image data is written to the FIFO memory, the count of the FIFO counter is incremented. When a unit of image data is read from the FIFO memory, the count of the FIFO counter is decremented.	

comparing the count of the FIFO counter with a FIFO limit;	The Eufy Camera compares the count of the FIFO counter with a FIFO limit.
	For example, the interface subsystem includes a FIFO limit which it compares to the FIFO count to determine if the amount of image data in the FIFO memory is at a "fill level" that will require the interface subsystem to take an action.
generating an interrupt signal to request a processor to transfer image data from the FIFO memory in response to an interrupt enable	The Eufy Camera generates an interrupt signal to request a processor to transfer image data from the FIFO memory in response to an interrupt enable signal being valid and the count of the FIFO counter having a predetermined relationship to the FIFO limit.
signal being valid and the count of the FIFO counter having a predetermined relationship to the FIFO limit; and	For example, the interface subsystem includes a processor for performing operations to transmit image data to the image processing subsystem. The servicing of interrupts by the processor can be enabled or disabled. When the servicing of interrupts from the FIFO memory is enabled and the count of the FIFO counter has a predetermined relationship to the FIFO limit, the interface subsystem generates an interrupt signal. The interrupt signal represents a request for the processor to transfer image data from the FIFO memory.
transferring image data from the FIFO memory to the processor in response	The Eufy Camera transfers image data from the FIFO memory to the processor in response to the interrupt signal.
to the interrupt signal.	For example, when the processor receives the interrupt signal, the processor transfers the image data from the FIFO memory to the processor, which transmits the image data to the image processing subsystem for processing.

Eufy - Cameras (See product list at end of chart for models) Infringement of the '242 patent		
Claim 8	Evidence	
8. A method of processing imaging signals, the method	The Eufy Camera performs a method of processing imaging signals.	
comprising:	For example, the Eufy Camera includes an image capturing subsystem, an image processing subsystem and an interface subsystem connecting them. The image processing subsystem processes imaging signals that are received from the image capturing subsystem via the interface subsystem.	
receiving image data from an imaging array;	The Eufy Camera receives image data from an imaging array.	
	For example, the image capturing subsystem includes a CMOS image sensor that includes an imaging array. The imaging array produces image data when exposed to an image. The interface subsystem of the Eufy Camera receives the image data from the imaging array.	
storing the image data in a FIFO memory;	The Eufy Camera stores the image data in a FIFO memory.	
	For example, the interface subsystem includes a FIFO memory for storing image data. The image data received from the imaging array is stored in the FIFO memory by the interface subsystem.	
updating a FIFO counter to maintain a count of the image data in the FIFO memory in response	The Eufy Camera updates a FIFO counter to maintain a count of the image data in the FIFO memory in response to memory reads and writes;	
to memory reads and writes;	For example, the interface subsystem includes a FIFO counter to maintain a count of the image data, or "fill level", that is stored in the FIFO memory. When a unit of image data is written to the FIFO memory, the count of the FIFO counter is incremented. When a unit of image data is read from the FIFO memory, the count of the FIFO counter is decremented.	

comparing the count of the FIFO counter with a FIFO limit;	The Eufy Camera compares the count of the FIFO counter with a FIFO limit.
with a rin o mine,	For example, the interface subsystem includes a FIFO limit which it compares to the FIFO count to determine if the amount of image data in the FIFO memory is at a "fill level" that will require the interface subsystem to take an action.
generating, in response to the count of the FIFO counter having a predetermined relationship to the	The Eufy Camera generates, in response to the count of the FIFO counter having a predetermined relationship to the FIFO limit, a bus request signal to request a bus arbitration unit to grant access to an output bus.
FIFO limit, a bus request signal to request a bus arbitration unit to grant access to an output bus; and	For example, the interface subsystem includes a bus arbitration unit and an output bus to which the image processing subsystem is connected. When the count of the FIFO counter has a predetermined relationship to the FIFO limit, the interface subsystem generates a bus request signal. The bus request signal represents a request for the bus arbitration unit to grant the interface subsystem access to the output bus.
transferring image data from the FIFO memory to the output bus in response to receiving a grant	The Eufy Camera transfers image data from the FIFO memory to the output bus in response to receiving a grant signal from the bus arbitration unit.
signal from the bus arbitration unit.	For example, after the bus arbitration unit receives the bus request signal it generates a grant signal that gives the interface subsystem access to the output bus. Upon receiving the grant signal, the image data is transferred from the FIFO memory to the output bus for processing by the image processing subsystem.

Product List

Indoor Cam 1080p, Indoor Cam 1080p Pan & Tilt Indoor Cam 2K, Indoor Cam 2K Pan & Tilt eufyCam, eufyCam 2, eufyCam 2C, eufyCam 2 Pro, eufyCam 2C Pro eufyCam E Floodlight Camera SpaceView Baby Monitor, SpaceView Pro Baby Monitor, SpaceView S Baby Monitor, 720p Video Baby Monitor Video Doorbell 2K, Video Doorbell 1080p

References

[1] Indoor Cam 2K Pan & Tilt https://us.eufylife.com/collections/indoor-cam

[2] Indoor Cam 1080p https://us.eufylife.com/collections/indoor-cam/products/t8401

[3] Floodlight Camera https://us.eufylife.com/collections/smart-floodlight/products/t8420

[4] Baby Monitor https://us.eufylife.com/collections/baby-monitor

[5] Battery Camera https://us.eufylife.com/collections/battery-camera

[6] Video Doorbell https://us.eufylife.com/collections/video-doorbell